


4本脚:丸/角 角型 H720

脚タイプ: ■=R(丸脚)、S(角脚)


奥行		正方形	W1200	W1500	W1800	W2100
D450	DCR-	——	124HN■TA1■□	154HN■TA1■□	184HN■TA1■□	214HN■TA1■□
D600	DCR-	——	126HN■TA1■□	156HN■TA1■□	186HN■TA1■□	216HN■TA1■□
D750	DCR-	077HN■TA1■□	127HN■TA1■□	157HN■TA1■□	187HN■TA1■□	217HN■TA1■□
D900	DCR-	099HN■TA1■□	129HN■TA1■□	159HN■TA1■□	189HN■TA1■□	219HN■TA1■□

アジャスタ付・塗装脚・配線なし仕様

[天板カラー：□]

L	H	M	R	X	Y
					
W9 ホワイトW	61 アッシュバインL	71 アッシュオークM	81 アッシュオークD	92 ホワイトオークM	82 ブラックウォールナットD

[脚カラー：■ (4本脚・T字脚テーブル)]

W	Z	T
		
W9 ホワイトW	Z5 シルバーメタリック	T1 ブラックT